



NOTES:

1. THICKNESS "B" OF SADDLE

- B = 6" WHEN: D < 12"
- B = 8" WHEN: 12" ≤ D < 24"
- B = 10" WHEN: 24" ≤ D < 36"
- B = 12" WHEN: 36" ≤ D < 48"

2. FOR "B"=10" OR THICKER, USE 2 LAYERS OF REINFORCING, TURN HORIZONTAL BARS 90° TO HOOK AROUND VERTICALS , 1 1/2" CLEAR OF CONCRETE

3. FORM 3/4" BEVEL ON ALL EXPOSED CORNERS OF SUPPORT.

CONCRETE PIPE SADDLE

NTS

CONCRETE SLAB
 DRILL AND ADHESIVE ANCHOR REINF INTO EXST CONC (0330-105) OR PROVIDE STD HOOKS AT EMBEDDED CONCRETE